



BOLT-ON C.V. BOOT KITS

Bolt-on Boots

The EMPI Bolt-On/Split Boot Style C.V. Boot Kits Section includes Bolt-On/Split Boot by Application, Clamps, Grease and Hardware for Bolt-On/Split Boots.

Quickly replace damaged C.V. Boots without removing the Axle! Our new 100% Neoprene Bolt-On/Split Boot Style C.V. Boot is perfect for the Do-It-Yourself customer. Easily bolts together in minutes with **NO GLUE** or special tools required.

This program currently consists of nineteen (19) C.V. Boot Kits that provide coverage for the most popular outboard and some inboard applications.

While the Bolt-On/Split Boot Style C.V. Boot will not look like the O.E.M. Boot it is replacing, you can be assured that it was checked and tested to insure proper replacement.

If your customer requires a one-piece O.E.M. style replacement C.V. Boot, refer to the "C.V. Boots" listing in the front of this catalog.

Packaging:

Each Kit comes complete with Boot, Pack of Grease, Installation Instructions, a set of Mounting Clamps, Bolts & Nuts, and is packaged in our distinctive EMPI 4-Color, Tri-Lingual "Clam-Shell" package. The Installation Instructions include pictures and are written in English, French and Spanish. The Mounting Clamps are designed for easy installation and can be installed with a common pliers. Details can be found within the Installation Instructions.

To order, simply look up the application by make, model and year and place your order using the EMPI part number listed for that application. If the application guide does not specify driver or passenger, the boot fits both sides.



EMPI Clam-Shell packaging will allow Boot to be placed on a peg hook or stand up on a shelf.

86-2857-C